
UTensor II Installation

Before installation: The face of the bolt that the sensor is to be mounted on should be ground to a surface finish of approximately N7, and the opposite end should be ground parallel to the face within 0.5 degrees.



5- Place a super magnet on the tape to supply constant pressure for adhesive curing.
6- After the adhesive has finished curing, remove the magnet and peel off the tape.
7- You can clean off excessive adhesive with a cotton swab and acetone.
8- Place the Magnetic pick-up unit on top of the UTensor II to transmit and receive pulses from the bolt.